



Instruction Booklet  
사용설명서



1800W  
PROFESSIONAL HAIR DRYER

1800W  
프로페셔널 드라이어

VSD180K

salon tools

**VS 1800W PROFESSIONAL DRYER**

The VS 1800W PROFESSIONAL DRYER has 1800W of power for fast drying. It has 3 heat / speed settings and comes with a concentrator nozzle.

**IMPORTANT SAFETY INSTRUCTIONS**

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

**READ ALL INSTRUCTIONS BEFORE USING  
KEEP AWAY FROM WATER**

**SAFETY PRECAUTIONS**

**WARNING:** The polyethylene bags over the product or its packaging may be dangerous. Keep these bags out of the reach of babies and children. Never use them in cribs, children's beds, pushchairs or playpens. The thin film may cling to the nose and mouth and prevent breathing. A bag is not a toy.



**WARNING:** Do not use this appliance near bathtubs, showers, basins or other vessels containing water.

1. If you are using the unit in a bathroom, unplug it after you have finished using it. Using the unit close to a source of water can, in fact, be dangerous, even if the unit is switched off. To ensure additional protection, have installed in your bathroom a residual current device (RCD) with a nominal trip current no higher than 30 mA. Ask your electrical fitter for advice.
2. Never immerse the unit in water or any other liquid.
3. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
4. When using the unit, make sure the unit's air vent is not blocked. Make sure there is no hair or any other dirt obstructing the unit's rear filter.
5. This unit has been equipped with a temperature cut-out. If the unit overheats, it will shut off automatically or will stop heating. If this happens, slide the switch on the unit's handle into the OFF position, unplug the unit and allow it to cool for 10 minutes. BEFORE using it again, make sure there is no hair or any other dirt in the unit's rear filter. Plug the unit in and switch it on. If it overheats again, stop using it immediately, switch it off and unplug it. Return the unit to the CONAIR service centre.
6. Do not use the unit if it has fallen or if it appears to be damaged.
7. Do not leave the unit unattended when it is plugged in or switched on.
8. Unplug the unit immediately if you have problems when using it.
9. Do not use any accessories other than those recommended by manufacturer.
10. Unplug the unit after each use and before cleaning it.
11. Avoid any contact between the unit's hot surfaces and your skin, in particular, your ears, eyes, face and neck.
12. This unit is not intended for use by people (including children) with reduced physical, sensory or mental capabilities, or by persons who lack experience or knowledge, unless they are

supervised or have been given instructions beforehand on the use of the unit by a person responsible for their safety. Children should be supervised to make sure they do not treat the unit like a toy.

13. Allow the unit to cool before storing.
14. To prevent damage to the cord, do not wrap it around the unit and ensure it is stored without twisting or folding it.

**FEATURES:**

1. 1800W
2. 3 heat / speed settings
3. Cool shot button
4. Concentrator nozzle
5. Hanging loop
6. Detachable Filter



**INSTRUCTIONS FOR USE**

**GENERAL**

- Towel dry and detangle the hair.
- There are 3 heat / speed settings. Use a high heat/speed setting for rough drying. Use the low heat/speed setting as hair begins to dry and for styling and scrunch drying.
- Use the cool shot button on warm hair to "set" a curl or wave.
- After use, switch off and unplug the appliance. Allow to cool before storing away.

**HOW TO USE THE CONCENTRATOR NOZZLE**

The concentrator nozzle is great for straightening or styling hair with a brush. Use the professional concentrator nozzle for directing the air just where you want it. For additional control use one of the lower settings and point the air-flow along the surface of the hair to be dried.

**COOL SHOT BUTTON**

Use the cool shot button on warm hair to set the wave or curl in place for a really long lasting effect.

**STYLING TIPS  
BODY & VOLUME**

To help create extra body and volume in the hair, tilt your head forward so the hair is upside down when drying. Position the airflow towards the roots for maximum lift. When hair is dry brush in to desired style.

**STRAIGHTENING**

To create a super straight look, first divide the hair into sections then using a brush and the concentrator nozzle, hold hair taut and let the brush glide down the hair as you dry.

**CLEANING THE FILTER**

- Ensure the appliance is switched off, unplugged and cool.
- Hold the handle of the dryer and turn the side filter cover away from the dryer in counterclockwise direction.
- Using a soft brush, clean any hair and other debris from the filter.
- Replace the side filter cover by turning back into position in clockwise direction.

**IMPORTANT!**

This appliance should only be used as described within this instruction booklet. Please retain for reference.

**USER MAINTENANCE**

Your dryer is virtually maintenance-free. No lubrication is needed. For proper operating performance, the dryer must be kept clean. Blocked or clogged air intake vents will cause the dryer to overheat. When cleaning is needed, unplug the cord, and clean dust and lint from air intake openings with a small brush or the brush attachment of a vacuum cleaner. The outer surface of the dryer should be wiped clean with a damp cloth only.

**CAUTION**

NEVER allow the power supply cord to be pulled, twisted, or severely bent. Never wrap the cord tightly around the dryer. Damage will occur at the high flex point of entry into the dryer, causing it to rupture and short. Inspect the cord frequently for damage. Stop use immediately if damage is visible or unit stops or operates intermittently.

**STORAGE**

When not in use, your dryer should be disconnected and stored in a safe, dry location, out of reach of children. Do not wrap line cord around dryer.

**THE DATE CODE MENTIONED**

WWYYXXX was mentioned on unit as manufactured date so you can see W as week and Y as year for your reference.

**CONTINENTAL CONAIR LIMITED  
CHINA CREATIVE DEPARTMENT**

Date	07/27/2016
Customer	VS-KOREA(K)
Model No.	VSD180K
Description	IB
Job No.	16VS075
Reference No.	IB-16/281
Revision No.	0
Color	1C+1C(Black)
Open Size	552mm(W) X 214mm(H)
Folded Size	92mm(W) X 214mm(H)
Material	80gsm Artpaper
Prepared by	KENSON CHEN
Approved by	Jimmy Ng/Elodie Lee
Vendor	Yueli
Supplier	



**수입 판매원**

콘에어코리아트레이딩주식회사  
서울시성동구성수이로 66  
서울숲드림타워 1304 ~ 1306호

A/S 대표 번호 : 1899-0209

자사의 A/S 전문대행업체인 필일렉 [www.fillelec.co.kr](http://www.fillelec.co.kr)  
의 홈페이지를 통해서  
가까운 A/S센터(전국 38개점)를 확인하세요

Conair Far East Ltd.,

A Subsidiary of Conair Corporate USA Conair Corporation USA,  
1 Cummings Point Road, Stamford, Connecticut 06902 USA  
[www.toolsofsassoon.com](http://www.toolsofsassoon.com)

Vidal Sassoon and related logos are trademarks of

The Procter & Gamble Company used under license by Conair Corporation.

折叠方法  
Folding method:  
12 pages (6 x 2)



VSD180K

IB-16/281

### VS 1800W 프로페셔널 드라이어

비달사순 1800W 프로페셔널 드라이어는 강력한 1800W 전력으로 모발을 빠르게 건조시킵니다. 본 제품은 3단계 온도 / 풍속 조절이 가능하며 집중 노즐이 포함되어 있는 상품입니다.

### 주요 안전 주의사항

제품 사용시 특히 어린이가 있을 경우 다음의 안전 주의사항을 반드시 준수하셔야 합니다.

### 사용 전 반드시 사용설명서를 숙지하여 주십시오. 물에 접촉하거나 빠뜨리시면 안됩니다.

#### 안전주의

**경고:** 제품 포장에 사용된 폴리에틸렌 재질의 포장재는 어린이가 사용할 경우 위험할 수 있습니다. 어린이의 손이 닿지 않도록 주의해 주십시오. 이 포장재를 유아용 침대 혹은 유아차 등에서 사용하지 마십시오. 얇은 막이 코나 입에 붙어 유아가 질식될 수 있습니다. 포장재는 장난감이 아닙니다.

얇은 필름으로 인해 유아가 질식될 수 있습니다.

**경고:** 이 제품을 욕조, 샤워기, 세면대 등 물이 닿기 쉬운 곳에서 사용하지 마십시오.

- 전원을 연결하거나 스위치를 켜 상태에서 제품을 보관하지 마십시오.
- 제품 사용 중 문제가 있을 경우 즉시 플러그를 뽑아 주십시오.
- 제조업체가 공급하는 부속품 외의 부속품을 사용하지 마십시오.
- 제품 사용 후나 제품 세척 전에 반드시 플러그를 뽑아 주십시오.
- 피부, 특히 귀, 눈, 목 등을 제품의 뜨거운 열판 송풍구에 닿지 않도록 각별히 주의하셔야 합니다.
- 본 제품은 영유아, 어린이, 심신 박약자, 심신 상실자, 정신 질환자 등에 의해 사용되어서는 안되며, 사용 시에는 반드시 보호자의 보호가 필요합니다. 특히 어린이가 장난감처럼 사용하지 않도록 각별히 보호해 주십시오.
- 제품 보관 시 반드시 제품을 식혀 주십시오.
- 전원코드의 손상을 막기 위해 꼬거나 구부러져 보관하지 말아주십시오.

### 제품의 특징

- 1800W
- 3단계 온도 / 풍속 조절
- 쿨샷 버튼
- 집중 노즐
- 보관이 용이한 걸이용 고리
- 탈부착 가능한 필터



- 부득이 물이 있는 곳에서 사용하실 경우 사용 후 반드시 플러그를 뽑아 주십시오. 전원 스위치가 꺼져 있더라도 물 근처에서 사용하시면 위험합니다. 보다 안전한 사용을 위하여 욕실의 잔류전류 용량은 30mA이하여야 합니다. 욕실 등에서 사용 시 위 사항을 참조하여 전문가와 상의 후 사용하시기 바랍니다.
- 물 또는 액체에 절대로 빠뜨리시면 안됩니다.
- 전원코드가 손상되었을 경우 A/S 센터에서 반드시 수리를 받으셔야 안전합니다.
- 제품 사용시 제품의 통풍구가 막히지 않았는지 확인 후 사용하십시오. 또한 제품후면의 흡입구가 먼지나 머리카락으로 막혀있지 않은지 확인하신 후 사용하십시오.
- 본 제품에는 온도 조절장치가 장착되어 있습니다. 만약 제품의 온도가 지나치게 상승하게 되면, 온도 조절장치에 의해 자동으로 전원이 꺼지거나 열이 더 이상 공급되지 않게 됩니다. 이와 같이 자동으로 꺼지는 일이 발생할 경우는 스위치를 끄시고 전원코드를 뽑으신 후 흡입구가 먼지나 모발에 의해 막히지 않았는지 확인하시고 약 10분 정도 기다리신 후 다시 사용하시기 바랍니다. 플러그와 스위치를 다시 작동시킨 후 사용해 보시고 이런 일이 다시 발생할 경우 즉시 사용을 중단하시고, A/S센터에 연락하십시오.
- 제품을 떨어뜨리거나, 제품이 손상된 것처럼 보일 경우 사용을 중단하시고 A/S센터에 연락하시기 바랍니다.

### 일반 사용법 안내

- 모발을 건조시키거나 자연스러운 컬을 연출하는데 사용합니다.
- 본 제품은 3단계 온도 / 풍속 조절이 가능합니다. 고온/고속 에 세팅하여 먼저 머리를 건조시키고, 머리가 건조되기 시작하면 저온/저속에 세팅하여 스타일링합니다.
- 쿨샷 버튼을 눌러 열이 가해진 모발에 냉풍을 가해, 컬이나 웨이브를 고정시켜 줍니다.
- 사용 후 전원을 끄고 플러그를 뽑아 열을 식혀 보관해 주십시오.

### 집중 노즐 사용

집중 노즐을 모발을 펴거나 브러시를 이용해 스타일링을 낼 때 활용하십시오. 집중 노즐은 공기를 원하는 부위에 집중적으로 공급하여 스타일링을 도와 줍니다. 섬세한 사용을 원하는 경우, 낮은 열풍으로 설정 후 모발표면을 따라 드라이를 해줍니다.

### 쿨샷버튼

쿨샷버튼을 눌러 열이 가해진 모발에 냉풍을 가해 웨이브를 고정시키면, 스타일이 오랫동안 지속됩니다.

### 스타일링 팁

#### 볼륨연출

풍성한 볼륨을 연출 하실 때에는 고개를 숙인 후 드라이를 합니다. 공기 흐름이 모근쪽에 향하도록 드라이 하여 최대한 모근을 세우면, 풍성한 볼륨 연출에 도움이 됩니다. 모발이 건조된 후에는 브러시로 모발을 빗어주어 원하는 스타일을 완성합니다.

### 스트레이트닝

찰랑거리는 스트레이트 스타일을 연출할 때에는 모발 섹션을 나누어 잡고 브러시와 집중 노즐로 스타일을 연출합니다. 모발을 단단히 잡고 모발에 브러시를 밀착시켜, 드라이 바람 방향에 따라 브러시를 내려줍니다.

### 필터 청소

- 드라이기 전원을 끄고 플러그를 분리한 후 열을 식혀줍니다.
- 한 손으로 드라이기 핸들을 잡고, 다른 한 손으로는 드라이기 옆면 필터를 잡아 시계 반대 방향으로 돌려 빼줍니다.
- 부드러운 솔로 필터의 먼지를 제거합니다.
- 시계 방향으로 필터를 돌려 제 자리에 다시 끼웁니다.

### 중요사항

본 제품 사용 안내서에 기재된 안내에 따라 제품을 사용하십시오. 사용 안내서는 계속 보관하시어 참고하시기 바랍니다.

### 사용시 주의사항

본 제품은 별도로 유지 보수를 필요로 하지 않습니다. 또한 윤활유를 필요로 하지 않습니다. 제품을 잘 활용하기 위해서는 제품을 반드시 깨끗한 상태로 유지 하여야 합니다. 차단되거나 막힌 공기 투입구는 드라이 과열의 원인이 됩니다. 세척이 필요한 경우, 전원을 끄고 열기가 식은 상태에서 공기 투입구를 개봉 후 작은 브러시를 이용하여 먼지와 이상물질을 제거 하도록 합니다. 드라이어의 표면은 젖은 천으로 닦아서 청소 합니다.

### 위험

절대로 전선을 잡아당기거나 끄는 등 심하게 구부리지 마시고 전선으로 기기를 너무 단단히 감지 마세요. 이는 전선의 손상 및 파열, 합선문제를 발생시킬 수 있습니다. 전선을 수시로 확인하시고 손상됐을 시엔 제품사용을 즉시 중단하시기 바랍니다.

### 제품 보관

제품을 사용하지 않을 때는 반드시 전원을 안전하게 분리한 후 제품의 열을 식힌 후 어린이의 손이 닿지 않는 안전하고 건조한 곳에 보관하십시오. 전원에서 분리할 때는 감자기 잡아 당기거나 너무 평평하게 전선을 잡아당기지 마시고 코드로 제품을 감지 마십시오.

### 제조일 표기

제조일은 본 제품에 WYYYXXX 형태로 표기되어 있습니다. W는 '몇째 주', Y는 '몇 년도'를 나타냅니다.

### 제품 품질 보증서

성 명	
전화번호	/휴대폰번호
e-mail	
주 소	
구입일자(년/월/일)	
모델번호(사용설명서 앞면 표기)	
대리점명(구입처)	

#### ■ 주의사항

- 서비스를 받고자 하실때는 이 보증서와 구입 영수증을 제시하여 주십시오.
- 제품 구입일자가 고쳐지거나, 지워졌을 경우에 본 보증서는 무효입니다.
- 이 보증서를 분실하실 경우, 재발행되지 않습니다.

### 본 보증서는 보관하십시오

#### ■ 품질 보증의 조건

- 본 제품의 품질보증 기간은 구입 일자로부터 2년간 입니다.
- 일상적인 사용에 의한 제품의 마모나, 마멸 또는 천재지변에 의한 제품의 손상 및 사용 설명서 상의 주의사항을 따르지 않고 임의로 사용하거나, 취급부주의로 인한 고장 등에 대해서는 본 보증서에 의한 무상 서비스를 받을 수 없습니다.
- 품질 보증서 상의 보증기간 내에는 제조상 또는 제질상의 결함으로 발생된 불량 등 에 대하여 무상 서비스를 받을 수 있으며 메사의 판단에 따라 부품의 교환 또는 제 품의 교환도 가능합니다.
- 본 보증서의 효력은, 품질 보증서와 보증 등록서상의 대리점의 판매 확인과 제품구 입 후 4주 이내 보증등록서가 고객 서비스 센터에 우송 되었을 때로부터 발생 됩니 다.
- 본 제품 품질보증은 수입판매원의 관할 이외 지역과 적법하게 위임 받지 않은 판매 처의 보증일 경우 효력을 상실합니다.

서비스를 받으시고자 할 경우 보증서의 내용을 기록하여 제품과 함께 보내주십시오.

<b>수입 판매원</b>
론에어코리아트레이딩주식회사 서울시성동구성수이로 66 서울숄드림타워 1304 ~ 1306호 A/S 대표 번호 : 1899-0209 자사의 A/S 전문대행업체인 필일렉 www.filetec.co.kr 의 홈페이지를 통해서 가까운 A/S센터(전국 38개점)를 확인하세요