



Instruction Booklet 사용설명서



SMOOTH CERAMIC STRAIGHTENER 스무스 세라믹 무빙 스트레이트너

VSS247K

VS SASSOON STRAIGHTENER

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING KEEP AWAY FROM WATER

SAFETY PRECAUTIONS

WARNING: The polyethylene bags over the product or its packaging may be dangerous. Keep these bags out of the reach of babies and children.

Never use them in cribs, children's beds, pushchairs or playpens. The thin film may cling to the nose and mouth and prevent breathing. A bag is not a toy.

WARNING: Do not use this appliance near bathtubs, showers, basins or other vessels containing water.

1. If you are using the unit in a bathroom, unplug it after you have finished using it. Using the unit close to a source of water can, in fact, be dangerous, even if the unit is switched off. To ensure additional protection, have installed in your bathroom a residual current device (RCD) with a nominal trip current no higher than 30 mA. Ask your electrical fitter for advice.
2. Never immerse the unit in water or any other liquid.
3. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
4. Do not use the unit if it has fallen or if it appears to be damaged.
5. Do not leave the unit unattended when it is plugged in or switched on.
6. Unplug the unit immediately if you have problems when using it.
7. Do not use any accessories other than those recommended by manufacturer.
8. Unplug the unit after each use and before cleaning it.
9. Avoid any contact between the unit's hot surfaces and your skin, in particular, your ears, eyes, face and neck.
10. This unit is not intended for use by people (including children) with reduced physical, sensory or mental capabilities, or by persons who lack experience or knowledge, unless they are supervised or have been given instructions beforehand on the use of the unit by a person responsible for their safety. Children should be supervised to make sure they do not treat the unit like a toy.
11. Allow the unit to cool before storing.
12. To prevent damage to the cord, do not wrap it around the unit and ensure it is stored without twisting or folding it.

OPERATING INSTRUCTIONS

This straightening iron appliance is intended for household use. This unit is designed to operate at 220 volts AC. Use on Alternating Current (60 hertz) only.

GET TO KNOW YOUR STRAIGHTENER



CERAMIC TECHNOLOGY

Ceramic Technology helps keep your hair looking healthy & shiny by maintaining even heat during the straightening process. Static is reduced by quickly sealing the hair cuticle layer ensuring minimal frizz making your hair easier to manage.

OPERATING INSTRUCTIONS

Wash, condition & dry your hair as normal. Ensure your hair is combed through & tangle-free.

1. Plug your straightener into any household outlet 220V, place on a heat protective, flat level surface.
2. Slide power switch to the 'I' setting to turn on.
3. Divide your hair into 4 sections (2 back & 2 front).
4. Starting with the back sections at the nape of the neck, take a horizontal section no wider than the plate of the straightener & clamp the plates over the section then glide down slowly & evenly.
5. Repeat this through all sections.
6. After use, turn your straightener off by sliding the power switch to the 'O' setting.

Allow straightener to cool before storing.

HOW TO STYLE WITH THE SMOOTH CERAMIC STRAIGHTENER

STRAIGHT

Start with clean & dry, thoroughly combed through hair. Apply a heat spray for extra protection & longer lasting results. Straighten your hair in sections ensuring you go over each section once to get that gorgeous, silky finish. If you are needing to go over the section more than once, creating thinner sections will help create straight hair in the first glide.

VOLUME

Create volume by making a curved movement with your wrist as you glide the straightener down the hair section.

EXPERT TIP

Set your style with a spritz of light hold hair spray, for extra hold if needed.

MAINTENANCE

Your straightening iron is virtually maintenance-free. No lubrication is needed. Keep all openings clear of dirt and dust. If cleaning becomes necessary, disconnect the unit from the power source, allow to cool, and wipe exterior with a cloth. If any abnormal condition occurs, unplug the unit, allow it to cool, and return it for repair to an authorized service representative only. No repairs should be attempted by the consumer.

However, in order to keep the best performance from your straightening iron all the time, please note the following care instructions.

- Do not scratch the surface of the plates with sharp objects or wipe with coarse material.
- Do not use this straightening iron with strong chemicals, like perm lotions.
- Do not clean the plates with strong cleaning agents. In most cases, mild detergent will be able to remove any stains or traces of styling products left on the plates easily.

CAUTION

NEVER allow the power supply cord to be pulled, twisted, or severely bent. Never wrap the cord tightly around the appliance. Damage will occur at the high flex point of entry into the appliance, causing it to rupture and short circuit. Inspect the cord frequently for damage. Stop use immediately if damage is visible or if unit stops or operates intermittently.

STORAGE

When not in use, your appliance is easy to store. Allow appliance to cool, then simply store out of reach of children in a safe, dry location. Do not jerk or strain cord at plug connections. Do not wrap the line cord around the appliance. Allow the cord to hang or lie loose and straight at the point of entry into the appliance.

THE DATE CODE MENTIONED

WWYYXXX was mentioned on unit as manufactured date so you can see W as week and Y as year for your reference.

Product size(mm)	270X38X30mm (w/o power cord)
Heat Plate size(mm)	25X90mm
Product weight(g)	335g (w/ power cord)
Heat Tempt. Setting	Max 200°C
Preheat Time	Approx. 1 minute to 115°C
Power Cord(m)	1.8m 360° Swivle Cord

제품 품질 보증서

성명

전화번호

e-mail

주소

구입일자(년/월/일)

모델번호(사용설명서 앞면 표기)

대리점명(구입처)

■ 주의사항

- 서비스를 받고자 하실때는 이 보증서와 구입 영수증을 제시하여 주십시오.
- 제품 구입일자가 고쳐지거나, 지워졌을 경우에 본 보증서는 무효입니다.
- 이 보증서를 분실하실 경우, 재발행되지 않습니다.

본 보증서는 보관하십시오

■ 품질 보증 조건

- 본 제품의 무상 수리 보증 기간은 2년입니다.
- 보증 기간 내에 정상적인 사용 중에 발생하는 고장에 대해서는 무상으로 수리하여 드립니다.
- 무상 보증 기간 내에 발생한 고장에 대해서 수리가 불가할 경우 폐사의 판단에 따라 부품의 교환 또는 유사한 제품으로 대체하여 드립니다.
- 보증 기간 내에도 다음과 같은 경우에는 원칙적으로 유상 수리하여 드립니다.
 - 사용상의 부주의 또는 비정상적인 수리 및 개조에 의한 경우
 - 사용설명서에 명시되어 있는 사항의 불이행으로 인하여 고장이 난 경우
 - 구입 후 운반이나 잘못된 보관 등에 의해 발생한 고장일 경우
 - 화재, 수해, 열해, 낙뢰 등의 천재지변 및 이상 전압 등에 의한 경우
 - 보증서에 구입하신 년월일, 고객이름, 대리점 등의 기재사항이 없거나 허위로 기재된 경우
- 본 보증서는 대한민국 국내에서만 유효합니다.
- 본 보증은 수입판매원의 관할 이외 지역(해외 포함) 또는 폐사로부터 적법하게 위임 받지 않은 판매처에서 구매하신 경우 효력을 상실합니다.
- 보증서에 명시되어 있지 않은 사항에 대해서는 통상적인 규정에 따라 처리하여 드립니다.
- 본 제품은 가정용이므로 가정용 이외로 사용하셨을 경우 무상수리가 불가능 합니다.
- 정격 전압이 아닌 곳에서 사용하여 발생한 문제는 책임지지 않습니다.

서비스를 받으시고자 할 경우 보증서의 내용을 기록하여 제품과 함께 보내주십시오.

수입 판매원

콘에어코리아트레이딩주식회사

소비자상담실 : 1899-0209

A/S센터 : 자사의 A/S대행업체인 필일렉 www.fillielec.co.kr의 홈페이지를 통해서 가까운 A/S센터(전국 38개점)를 확인하세요

CONTINENTAL CONAIR LIMITED CHINA CREATIVE DEPARTMENT

Date	12/8/2021
Customer	CKTL
Model No.	VSS247K
Description	IB
Job No.	
Reference No.	IB-21/308
Revision No.	0
Color	1C+1C(Black)
Open Size	460mm(W) X 214mm(H)
Folded Size	92mm(W) X 214mm(H)
Material	80gsm Artpaper
Prepared by	Betty Bai
Approved by	Ken Xiong
Vendor	YUELI
Supplier	

折疊方法
Folding method:
10 pages (5X2)





비달사순 스무스 세라믹 스트레이트너

주요 안전 주의사항

제품 사용 시 특히 어린이가 있을 경우 다음의 안전 주의사항을 반드시 준수 하셔야 합니다.

사용 전 반드시 사용설명서를 숙지하여 주십시오. 물에 접촉하거나 빠뜨리시면 안됩니다.

안전주의

경고: 제품 포장에 사용된 폴리에틸렌 재질의 포장재는 어린이가 사용할 경우 위험할 수 있습니다. 어린이의 손이 닿지 않는 안전한 곳에 두십시오. 유아 및 어린이 침대, 유모차, 어린이 놀이지역 안에서는 절대 사용하지 마십시오. 포장재는 장난감이 아닙니다. 얇은 막이 코나 입에 붙어 유아나 어린이가 질식 될 수 있습니다.



경고: 이 제품을 욕조, 샤워기, 세면대 등 물이 닿기 쉬운 곳에서 사용하지 마십시오.

- 부득이 물이 있는 곳에서 사용하실 경우 사용 후 반드시 플러그를 뽑아 주십시오. 전원 스위치가 꺼져 있더라도 물 근처에서 사용하시면 위험합니다. 보다 안전한 사용을 위하여 욕실의 잔류전류 용량은 30mA 이하여야 합니다. 욕실 등에서 사용 시 위 사항을 참조하여 전문가와 상의하시기 바랍니다.
- 물 또는 액체에 절대로 빠뜨리시면 안 됩니다.
- 전원코드가 손상된 경우 사용을 중단 하시고 즉각 A/S 센터에 연락하십시오.
- 떨어뜨리거나 손상된 기기는 즉각 사용을 중단하시고 A/S센터에 연락하십시오.
- 전원이 연결된 상태이거나 스위치를 켜 상태에서 제품을 방치 및 보관하지 마십시오.
- 제품 사용 중 문제가 있을 경우 즉시 전원을 끄고 플러그를 뽑아 주십시오.
- 제조업체가 공급하는 부속품 외의 부속품을 사용하지 마십시오.
- 제품 사용 후나 제품 세척 전에 반드시 전원을 끄고 플러그를 뽑아주십시오.
- 기기의 고온 표면에 피부(특히 귀, 눈, 얼굴 및 목 부위)에 닿지 않도록 주의 하셔야 합니다.
- 본 제품은 영, 유아, 어린이, 심신 박약 자, 심신 상실자, 정신 질환자 등에 의해 사용되어서는 안 되며, 사용 시에는 반드시 보호자의 보호가 필요합니다. 특히 어린이가 장난감처럼 사용하지 않도록 각별히 보호해 주십시오.
- 제품 보관 전 반드시 기기가 완전히 식은 상태에서 보관 하십시오.
- 전원코드의 손상을 막기 위해 전선을 기기에 맡거나

과도하게 구부러서 보관하지 마십시오.

제품 상세



제품 안내

본 기기는 220V, ~60Hz이며 가정용입니다.

세라믹 코팅 테크놀로지

세라믹 코팅 테크놀로지는 스트레이트너를 사용하는 동안 균일한 열을 유지하여 모발의 큐티클 층을 빠르게 정리하고 곱슬거림을 최소화하여 모발 손상을 최소화하고 윤기나는 모발을 유지해 줍니다.

사용 방법

머리를 감은 후 완전히 마른 상태에서 영킨 부분이 없도록 빗질한 상태로 사용 하시는 것을 권장합니다.

- 적정 전압을 확인 한 후 전원코드를 꽂아주세요. 기기가 뜨거워지니 표면이 상하지 않도록 주의하십시오.
- 전원 스위치를 위로 올려 'I' 전원을 켜주세요.
- 스타일링을 원하는 곳의 모발을 나눠 적당량을 잡아주세요..
- 모발을 열판 사이에 넣고 두피에 닿지 않게 주의하며 뿌리 쪽부터 아래로 부드럽게 내려 주세요. 과도하게 모발을 넣을 경우 열판 밖으로 나가 모발이 뜰거나 상할 수 있습니다.
- 위 과정을 반복하시어 원하시는 스타일링을 마무리하세요.
- 사용 후에는 반드시 전원을 'O'에 놓아 끄고 기기를

완전히 식혀 주세요.

어린이의 손이 닿지 않는 곳에서 완전히 식힌 후 보관하십시오.

추가 사용 팁

스트레이트/매직

모발이 완전히 마른 상태에서 영킨 부분이 없도록 빗질해 주세요. 손상모거나 얇은 모발의 경우 모발 보호를 위해 헤어용 열 보호크림이나 열 에센스를 도포 하신 후 사용하시기를 권장합니다. 기기 사용 전 열판을 넘지 않을 정도의 적당량의 모발을 잡아 섹션을 나눈 후 열판에 넣어 주세요. 뜨거운 열판이 두피나 피부에 직접 닿지 않도록 주의하며 뿌리 쪽에서 아래로 부드럽게 내려주세요. 모발의 상태에 따라 2회 정도 반복하시어 스타일링을 마무리하세요.

컬링

비달사순 스트레이트너를 아래쪽으로 동글게 말면서 내리면 자연스러운 C컬/S컬 웨이브 스타일링이 가능합니다.

스타일링 유지 팁

스타일링 후 스프레이, 왁스, 픽서 등을 사용하면 보다 오랫동안 유지하실 수 있습니다.

제품 관리

본 제품은 전기용품으로 직접 물이 닿지 않도록 주의하십시오. 제품이 오염된 경우 마른 천 혹은 물기를 꼭 짰 천으로 부드럽게 닦아 주시고 충분히 말려 주십시오. 절대로 제품 세척에 화학약품 등을 사용하지 마십시오. 사용 중 제품 이상이 있는 경우 즉각 전원을 차단하신 후 A/S센터에 문의하십시오. 절대로 직접 제품을 분해하거나 수리하지 마십시오.

- 절대로 열판이나 제품 표면을 날카로운 물건으로 긁지 마십시오.
- 절대로 파마약이나 산성물질이 강한 화학약품과 함께 사용하지 마십시오
- 절대로 강한 산성의 세척제로 제품을 닦지 마십시오. 오염이 생긴 경우 마른 천이나 물기를 꼭 짰 천으로 부드럽게 닦아 주십시오.

사용상 안전사항

절대로 전원 플러그를 강하게 잡아당기거나 전원 코드를 제품에 감거나 비틀지 마십시오. 전원 코드 내부에 손상이 생겨 기기가 파열되거나 화재의 위험이 있습니다. 전원 플러그 및 코드에 손상이 생긴 경우 즉각 사용을 멈춘 후 A/S센터에 문의 하십시오.

제품 보관

본 제품을 사용 하지 않을 때에는 제품이 완전히 식은 상태에서 어린이의 손이 닿지 않는 안전하고 건조한 장소에 보관하십시오. 전원 플러그 및 코드가 과도하게 구부러지거나 꼬이지 않도록 느슨한 상태로 보관하십시오.

제조일 표기

제조일은 본 제품에 WWYYXX형태로 표기되어 있습니다. W는 '주', Y는 '년도'를 나타냅니다.

제품 크기(mm)	270X38X30mm (전원코드 제외)
열판 크기(mm)	25X90mm
제품 무게(g)	335g (전원코드 포함)
최대 온도	최대 200°C
예열 시간	115°C까지 약 1분
전원 코드(m)	1.8m 360° 회전식 전원코드

수입 판매원

콘에어코리아트레이딩주식회사

소비자상담실 : 1899-0209
A/S센터: 자사의 A/S대행업체인 필일렉 www.fillelec.co.kr의 홈페이지를 통해서 가까운 A/S센터(전국 38개점)을 확인하세요

Conair Korea Trading Limited
www.vidalsassoon.kr

Certain trademarks used under license from The Procter & Gamble Company or its affiliates.

VSS247K

IB-21/308