



Instruction Booklet 사용설명서



2000W TOURMALINE CERAMIC IONIC HAIR DRYER 2000W 토크말린 세라믹 이온 헤어 드라이어

VS5543PIK



VS SASSOON 2000W TOURMALINE CERAMIC IONIC HAIR DRYER

We hope you enjoy using it. From our origins in salons, we have always been driven by a simple truth: every woman deserves to look fabulous without spending a fortune. Your 2000W ionic diffuser hair dryer is dedicated to creating hair care and styling products that are salon quality without the salon price. Salon inspired, stylist tested products to help you create your own style and experience that salon feeling every day.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING KEEP AWAY FROM WATER

SAFETY PRECAUTIONS

WARNING: The polyethylene bags over the product or its packaging may be dangerous. Keep these bags out of the reach of babies and children. Never use them in cribs, children's beds, pushchairs or playpens. The thin film may cling to the nose and mouth and prevent breathing. A bag is not a toy.



WARNING: Do not use this appliance near bathtubs, showers, basins or other vessels containing water.



1. If you are using the unit in a bathroom, unplug it after you have finished using it. Using the unit close to a source of water can, in fact, be dangerous, even if the unit is switched off. To ensure additional protection, have installed in your bathroom a residual current device (RCD) with a nominal trip current no higher than 30 mA. Ask your electrical fitter for advice.
2. Never immerse the unit in water or any other liquid.
3. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
4. When using the unit, make sure the unit's air vent is not blocked. Make sure there is no hair or any other dirt obstructing the unit's rear filter.
5. This unit has been equipped with a temperature cut-out. If the unit overheats, it will shut off automatically or will stop heating. If this happens, slide the switch on the unit's handle into the OFF position, unplug the unit and allow it to cool for 10 minutes. BEFORE using it again, make sure there is no hair or any other dirt in the unit's rear filter. Plug the unit in and switch it on. If it overheats again, stop using it immediately, switch it off and unplug it. Return the unit to the VS SASSOON service centre.
6. Do not use the unit if it has fallen or if it appears to be damaged.
7. Do not leave the unit unattended when it is plugged in or switched on.

8. Unplug the unit immediately if you have problems when using it.
9. Do not use any accessories other than those recommended by manufacturer.
10. Unplug the unit after each use and before cleaning it.
11. Avoid any contact between the unit's hot surfaces and your skin, in particular, your ears, eyes, face and neck.
12. This unit is not intended for use by people (including children) with reduced physical, sensory or mental capabilities, or by persons who lack experience or knowledge, unless they are supervised or have been given instructions beforehand on the use of the unit by a person responsible for their safety. Children should be supervised to make sure they do not treat the unit like a toy.
13. Allow the unit to cool before storing.
14. To prevent damage to the cord, do not wrap it around the unit and ensure it is stored without twisting or folding it.

GET TO KNOW YOUR 2000W TOURMALINE CERAMIC IONIC HAIR DRYER



INSTRUCTION FOR USE

- Towel dry and detangle the hair.
- There are 3 heat/speed settings. Use a high heat/speed setting for rough drying. Use the low heat/speed setting as hair begins to dry and for styling or to get volume and curl into your hair.
- Use the cool shot button on warm hair to "set" your curl or wave.
- After use, switch off and unplug the appliance. Allow to cool before storing away.

TOURMALINE CERAMIC TECHNOLOGY

The Tourmaline Ceramic Technology features crushed tourmaline gem stone crystals infused with ceramic.

Tourmaline emits negative ions which dramatically reduce drying time and static electricity. Ceramic emit far infrared heat providing a gentle, even heat that is less damaging. The results are unsurpassed; faster, healthier drying with shiny, smooth results.

IONIC TECHNOLOGY

Many aspects of modern living, including air conditioning, contact with man-made fibres and air pollution contribute to a build-up of static electricity in the hair. Even brushing and towel drying the hair, can increase these levels causing the surface of the cuticle to become rough. Consequently, hair may have a dull appearance. High levels of static charge cause hair to become "fly-away" and difficult to style. The ion generator in this dryer produces a stream of negative ions which act to neutralise the static charge, smoothing the scales on the cuticle for shiny, smooth and manageable hair so you can achieve your desired style easily.

CONCENTRATOR NOZZLE

The concentrator nozzle is great for straightening or styling hair when using a brush. Use the professional concentrator nozzle for directing the air just where you want it. For additional control use one of the lower settings and point the air flow along the surface of the hair to be dried.

THE DIFFUSER

A diffuser gives you more control over your hair. It is kinder and more gentle to your hair than conventional blow drying. Diffused heat is perfect for enhancing natural curls and waves or creating some extra volume.

- Tilt your head forward and aim the diffuser upwards into your hair so that the warm air circulates freely throughout.
- Use your fingers to lift the hair up from the roots.
- When dry, arrange your hair as required.

IMPORTANT

Only use the diffuser with your dryer on the lowest heat / speed setting.

COOL SHOT BUTTON

Use the cool shot button on warm hair to set the wave or curl in place for a really long lasting effect.

USER MAINTENANCE

Your dryer is virtually maintenance-free. No lubrication is needed. For proper operating performance, the dryer must be kept clean. Blocked or clogged air intake vents will cause the dryer to overheat. When cleaning is needed, unplug the cord, and clean dust and lint from air intake openings with a small brush or the brush attachment of a vacuum cleaner. The outer surface of the dryer should be wiped clean with a damp cloth only.

If overheating occurs, an automatic safety device will shut the dryer or the heat off to prevent damage or personal injury. If the unit or the heat cycles off, unplug the cord and allow the dryer to cool for 10 to 15 minutes before restarting. Make sure

the air vents are clean.

CAUTION

Never allow the power supply cord to be pulled, twisted, or severely bent. Never wrap the cord tightly around the dryer. Damage will occur at the high flex point of entry into the dryer, causing it to rupture and short. Inspect the cord frequently for damage. Stop use immediately if damage is visible or unit stops or operates intermittently.

STORAGE

When not in use, your dryer should be disconnected and stored in a safe, dry location, out of reach of children. Do not wrap line cord around dryer.

THE DATE CODE MENTIONED

WVYYXXX was mentioned on unit as manufactured date so you can see W as week and Y as year for your reference.



CONTINENTAL CONAIR LIMITED CHINA CREATIVE DEPARTMENT

Date	06/04/2015
Customer	VS-Korea
Model No.	VS5543PIK
Description	IB
Job No.	14VS144
Reference No.	IB-11/002G
Revision No.	0
Color	1C+1C(Black)
Open Size	552mm(W) X 214mm(H)
Folded Size	92mm(W) X 214mm(H)
Material	80gsm Artpaper
Prepared by	Betty bai
Approved by	Jimmy Ng/Elodie Lee
Vendor	Silverplan
Supplier	

수입 판매원

콘에어코리아트레이딩주식회사
서울시성동구성수이로 66
서울숲드림타워 1304 ~ 1306호

A/S 대표 번호 : 1899-0209

자사의 A/S 전문대행업체인 필일렉 www.fillelec.co.kr
의 홈페이지를 통해서
가까운 A/S센터(전국 38개점)를 확인하세요

Conair Far East Ltd.,

A Subsidiary of Conair Corporate USA Conair Corporation USA,
1 Cummings Point Road, Stamford, Connecticut 06902 USA
www.toolsofsassoon.com


Vidal Sassoon and related logos are trademarks of

The Procter & Gamble Company used under license by Conair Corporation.

VS5543PIK

IB-11/002G

折疊方法
Folding method:
12 pages (6 x 2)



비달사순 2000W 토르말린 세라믹 이온 헤어 드라이어

비달사순의 모든 스타일러는 사용자 스스로 원하는 스타일을 집에서든 전문가가 연출한 것처럼 편리하고 완벽하게 연출 할 수 있도록 효율적인 용도로 제작 되었습니다. 비달사순 2000W 토르말린 세라믹 이온 디퓨저 드라이어는 섬세한 헤어 손질 과 스타일 연출 이 가능한 제품으로 전문가가 연출한 것과 같은 효과를 느끼실 수 있습니다. 전문가의 손길, 전문가적인 느낌의 제품은 원하는 스타일로 쉽게 연출이 가능하여 매일매일 전문 헤어 스타일러가 연출한 것 과 같은 효과를 느끼실 수 있습니다.

주요 안전 주의사항

제품 사용 시 특히 어린이가 있을 경우 다음의 안전 주의사항을 반드시 준수하여야 합니다.

사용 전 반드시 사용설명서를 숙지하여 주십시오. 물에 접촉하거나 빠뜨리시면 안됩니다.

안전주의

경고: 제품 포장에 사용된 폴리에틸렌 재질의 포장재는 어린이가 사용할 경우 위험할 수 있습니다. 어린이의 손이 닿지 않도록 주의해 주십시오. 이 포장재를 유아용 침대 혹은 요람 등에서 사용하지 마십시오. 얇은 필름으로 인해 유아가 질식될 수 있습니다.



경고: 이 제품을 욕조, 샤워기, 개수대 등 물이 닿기 쉬운 곳에서 사용하지 마십시오.



- 부득이 물이 있는 곳에서 사용하실 경우 사용 후 반드시 플러그를 뽑아 주십시오. 전원 스위치가 꺼져 있더라도 물 근처에서 사용하시면 위험합니다. 보다 안전한 사용을 위하여 욕실의 잔류전류 용량은 30mA 이하여야 합니다. 욕실 등에서 사용 시 위 사항을 참조하여 전문가와 상의하시기 바랍니다.
- 물 또는 액체에 절대로 빠뜨리시면 안 됩니다.
- 전원코드가 손상되었을 경우 A/S 센터에서 반드시 수리를 받으셔야 안전합니다.
- 제품 사용 시 제품의 통풍구가 막히지 않았는지 확인 후 사용하십시오. 또한 제품 후면의 흡입구가 먼지나 머리카락으로 인해 막혀있지 않은지 확인하신 후 사용하십시오.
- 본 제품에는 온도휴즈가 장착되어 있습니다. 만약 제품의 온도가 지나치게 상승하게 되면, 온도휴즈에 의해 자동으로 전원이 꺼지게 되거나 열이 더 이상 공급되지 않게 됩니다. 이와 같이 자동으로 꺼지는 일이 발생할 경우는 스위치를 끄시고 전원코드를 뽑으신 후 흡입구가 먼지나 모발에 의해 막히지 않았는지 확인하시고 약 10분 정도 기다리신 후 다시 사용하시기 바랍니다. 플러그와 스위치를 다시 작동시킨 후 사용해 보시고 이런 일이 다시 발생할 경우 즉시 사용을

중단하시고, A/S센터에 연락하십시오.

- 제품을 떨어뜨리거나, 제품이 손상된 것처럼 보일 경우 사용을 중단하시고 A/S센터에 연락하시기 바랍니다.
- 전원을 연결하거나 스위치를 켜 상태에서 제품을 보관하지 마십시오.
- 제품 사용 중 문제가 있을 경우 즉시 플러그를 뽑아 주십시오.
- 제조업체가 공급하는 부속품 외의 부속품을 사용하지 마십시오.
- 제품 사용 후나 제품 세척 전에 반드시 플러그를 뽑아주십시오.
- 피부, 특히 귀, 눈, 목 등을 제품의 뜨거운 열판 사이에 닿지 않도록 각별히 주의하셔야 합니다.
- 본 제품은 영,유아, 어린이, 심신 박약자, 임신 산실자, 정신 질환자 등에 의해 사용되어서는 안 되며, 사용 시에는 반드시 보호자의 보호가 필요합니다. 특히 어린이가 장난감처럼 사용하지 않도록 각별히 보호해 주십시오.
- 제품 보관시 반드시 제품을 식혀 주십시오.
- 전원코드의 손상을 막기 위해 꼬거나 구부러져 보관하지 말아 주십시오.

2000W 토르말린 세라믹 이온 헤어드라이어 사용방법



제품 사용 용도 설명

- 먼저 수건으로 꼼꼼히 건조하고 모발을 엉키지 않게 합니다.
- 3단계 열풍조절 기능. 최고단계의 열풍으로 초도 드라이를 합니다. 최저단계의 열풍을 사용하여 드라이 와 스타일링

또는 볼륨연출이나 컬링 스타일을 연출 하도록 합니다.

- 냉풍 버튼을 이용 하여 차가운 바람으로 연출된 컬과 웨이브를 고정 하도록 합니다.
- 사용 후에는 반드시 전원을 차단하고 플러그에서 분리 후 차가운 상태로 보관합니다.

TOURMALINE CERAMIC 공법

토르말린 세라믹 공법은 토르말린 보석을 갈아서 세라믹과 결합시킨 기술입니다. 토르말린은 음이온을 발생하여 획기적으로 드라이 시간을 단축하고 정전기발생을 줄여줍니다. 세라믹은 원적외선을 방출하여 열풍으로 부드럽고 열풍으로도 손상을 줄여줍니다. 그 결과 가장 우월한 성능으로 가장 빠르고 윤기 나고 부드러운 건강한 모발건조를 도와 줍니다.

IONIC 기술

현대환경의 많은 요소인 에어컨은 인간이 만든 섬유 와 오염된 공기와 접촉하며 정전기를 일으켜 모발에 영향을 줄 수 있습니다. 심지어 빗질을 하거나 타월로 모발을 건조하여도 모발의 표피와 표면을 거칠게 할 수 있습니다 따라서, 모발의 심한 손상을 초래 할 수 있습니다. 또한 높은 수준의 정전기는 모발을 날리게 하여 스타일 연출을 어렵게 합니다. 음이온은 모발의 정전기를 중성화 하여 모발의 표면을 매끄럽고 부드럽게 하여 윤기 있는 모발로 연출하여 쉽게 원하는 헤어스타일 연출을 도와 줍니다

중앙 집중 노즐

중앙 집중 노즐은 브러쉬를 이용하여 스타일링 하거나 스트레이트 연출에 적합합니다. 중앙집중 노즐은 공기를 이용하여 원하는 부위에 직접적으로 스타일 연출을 도와 줍니다. 섬세한 사용을 원하는 경우 낮은 열풍으로 설정 후 모발 표면에 따라 모발을 건조합니다.

볼륨 디퓨저

디퓨저는 모발을 좀 더 효과적으로 건조 할 수 있습니다. 일반적인 드라이보다 모발을 좀더 부드럽게 건조 시킵니다. 디퓨저의 열풍은 완벽하고 자연스런 컬을 연출 합니다. 머리를 숙인 후 디퓨저를 고정한 후 공기가 자연스럽게 통 할 수 있도록 합니다. 모발의 뿌리를 손가락으로 세운 뒤 사용 하도록 합니다. 모발이 건조되면 모발을 편한 스타일로 정리하여 자연스럽게 연출 합니다.

중요

디퓨저의 사용은 낮은 온도의 열풍으로 셋팅 되었을 때만 사용 합니다.

냉풍 버튼

냉풍 버튼의 사용은 따스한 모발의 온도에서 웨이브나 컬을

오래도록 유지하는 효과를 위해 사용 합니다.

사용시 주의 사항

이 드라이기는 사실상 정비를 필요하지 않습니다. 윤활유 첨부를 필요로 하지 않습니다. 적절한 사용관장을 위해서는 드라이기는 항상 계속 깨끗한 상태로 유지 하여야 합니다. 차단 또는 막힌 공기 투입구는 드라이 시 과열에 원인이 됩니다. 세척이 필요한 경우, 전원을 차단 하고 에어 투입구를 개봉 후 작은 브러쉬를 이용하거나 진공 청소기의 브러쉬를 이용하여 먼지와 이상 물질을 제거 하도록 합니다. 드라이어의 다른 측면의 표면은 젖은 천으로 닦아서 청소합니다.

만일 과열될 경우 전원이 자동으로 차단 되며 작동이 중지되어 제품 손상을 예방하고 다칠 수 있는 부상을 방지합니다. 제품이 자동 전원 차단 될 경우 전원을 차단 후 플러그를 분리 후 제품을 10-15분 정도 차갑게 한 후 다시 사용 하도록 합니다. 사용 전 반드시 에어 통풍구의 청소상태를 확인 하십시오.

위험

절대로 전원 공급 장치 코드를 잡아 당기거나 꼬거나 또는 말지 마세요. 절대로 코드를 드라이어 주위에 말지 마세요. 제품의 손상의 파열은 구부러지는 부분 또는 잘려지는 데서 시작 됩니다. 코드에 대해 손상되었는지 자주 검사 하도록 합니다. 만일 손상의 정도가 보이거나 제품이 멈추었을 때 작동을 자꾸 멈추는 경우 사용을 즉시 중지 하십시오.

제품 보관

사용을 하지 않을 때 에는 반드시 안전하게 전원을 분리하고 아이들의 손에 닿지 않는 곳에 보관합니다. 코드로 드라이기 주위를 둘러서 말지 마십시오.

제조일 표기

제조일은 본제품에 WWYYXXX 형태로 표기되어 있습니다. W는 ‘ 몇 째 주’, Y는 ‘몇 년도’ 를 나타냅니다.

제품 품질 보증서

성명	
전화번호	/휴대폰번호
e-mail	
주소	
구입일자(년/월/일)	
모델번호(사용설명서 앞면 표기)	
대리점명(구입처)	

■ 주의사항

- 서비스를 받고자 하실때는 이 보증서와 구입 영수증을 제시하여 주십시오.
- 제품 구입일자가 고쳐지거나, 지워졌을 경우에 본 보증서는 무효입니다.
- 이보증서를 분실하실 경우, 재발행되지 않습니다.

본 보증서는 보관하십시오

■ 품질 보증의 조건

- 본 제품의 품질보증 기간은 구입 일자로부터 2년간 입니다.
- 일상적인 사용에 의한 제품의 마모나, 마멸 또는 천재지변에 의한 제품의 손상 및 사용 설명서 상의 주의사항을 따르지 않고 임의로 사용하거나, 취급부주의로 인한 고장 등에 대해서는 본 보증서에 의한 무상 서비스를 받을 수 없습니다.
- 품질 보증서 상의 보증기간 내에는 제조상 또는 재질상의 결함으로 발생한 불량 등 에 대하여 무상 서비스를 받을 수 있으며 폐사의 판단에 따라 부품의 교환 또는 제품의 교환도 가능합니다.
- 본 보증서의 효력은, 품질 보증서와 보증 등록서상의 대리점의 판매 확인과 제품구입 후 4주 이내 보증등록서가 고객 서비스 센터에 우송 되었을 때로부터 발생 합니다.
- 본 제품 품질보증은 수입판매원의 관할 이외 지역과 적법하게 위임 받지 않은 판매처의 보증일 경우 효력을 상실합니다.

서비스를 받으시고자 할 경우 보증서의 내용을 기록하여 제품과 함께 보내주십시오.

수입 판매원
 콘에어코리아트레이딩주식회사
 서울시성동구성수이로 66 서울송도림타워 1304 ~ 1306호
 A/S 대표 번호 : 1899-0209
 자사의 A/S 전문대행업체인 필일렉 www.fillelec.co.kr 의 홈페이지를 통해서 가까운 A/S센터(전국 38개점)를 확인하세요