



Instruction Booklet 사용설명서



1600W IONIC CERAMIC TURBO DRYER

1600W 이온 세라믹 터보 드라이어

VS9142SK

salon tools

VS SASSOON 1600W IONIC CERAMIC TURBO DRYER

IONIC CONDITIONING

The air most of us live in today carries positive ions that maintain smoke, dust and airborne particles found in air pollution. They leave the hair looking dull and brittle. The VS Sassoon 1600W Ionic Dryer generates negative ions to neutralize the positive ions, providing a full and complete coverage. Your hair is purified and deeply revitalised. The outer cuticle layer is fortified and smoothed leaving your hair looking shiny and healthy. Ions also help to split water molecules to smaller sizes, allowing them to easily penetrate hair, moisturising it inside and out.

CERAMIC CONDITIONING

Besides, the dryer is equipped with ceramic coated outlet. The ceramic provides increased heat distribution, eliminating the damaging hot spots found with other dryers. When introduced to heat, ceramic is known to emit ion reflectives. Assisting in the breakdown of bacteria build-up, the reflectives enhance and renew the vitality of your hair. This dryer will give your hair a smooth, silky shine while eliminating frizz.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING KEEP AWAY FROM WATER

SAFETY PRECAUTIONS

WARNING: The polyethylene bags over the product or its packaging may be dangerous. Keep these bags out of the reach of babies and children.

Never use them in cribs, children's beds, pushchairs or playpens. The thin film may cling to the nose and mouth and prevent breathing. A bag is not a toy.

WARNING: Do not use this appliance near bathtubs, showers, basins or other vessels containing water.

1. If you are using the unit in a bathroom, unplug it after you have finished using it. Using the unit close to a source of water can, in fact, be dangerous, even if the unit is switched off. To ensure additional protection, have installed in your bathroom a residual current device (RCD) with a nominal trip current no higher than 30 mA. Ask your electrical fitter for advice.
2. Never immerse the unit in water or any other liquid.
3. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
4. When using the unit, make sure the unit's air vent is not blocked. Make sure there is no hair or any other dirt obstructing the unit's rear filter.
5. This unit has been equipped with a temperature cut-out. If

the unit overheats, it will shut off automatically or will stop heating. If this happens, slide the switch on the unit's handle into the OFF position, unplug the unit and allow it to cool for 10 minutes. BEFORE using it again, make sure there is no hair or any other dirt in the unit's rear filter. Plug the unit in and switch it on. If it overheats again, stop using it immediately, switch it off and unplug it. Return the unit to the VS SASSOON service centre.

6. Do not use the unit if it has fallen or if it appears to be damaged.
7. Do not leave the unit unattended when it is plugged in or switched on.
8. Unplug the unit immediately if you have problems when using it.
9. Do not use any accessories other than those recommended by manufacturer.
10. Unplug the unit after each use and before cleaning it.
11. Avoid any contact between the unit's hot surfaces and your skin, in particular, your ears, eyes, face and neck.
12. This unit is not intended for use by people (including children) with reduced physical, sensory or mental capabilities, or by persons who lack experience or knowledge, unless they are supervised or have been given instructions beforehand on the use of the unit by a person responsible for their safety. Children should be supervised to make sure they do not treat the unit like a toy.
13. Allow the unit to cool before storing.
14. To prevent damage to the cord, do not wrap it around the unit and ensure it is stored without twisting or folding it.

INSTRUCTIONS FOR USE THE IONIC & CERAMIC CONDITIONING FEATURE

Many aspects of modern living, including air conditioning, contact with man-made fibres and air pollution, add to a build-up of static electricity in the hair. Even brushing and towel drying the hair can cause static electricity. This static charge causes the scales on the cuticle of the hair to push each other apart, a result of which is that the surface of the cuticle itself is rough and hairs cannot lie smoothly against each other. Consequently, hair may have a dull appearance. High levels of static charge cause hair to become "fly-away" and difficult to style. The negative ions, provide a complete coverage, which act to neutralise the static charge, smoothing the scales on the hair cuticle for shiny, smooth and manageable hair. Ions also help to split water molecules to smaller sizes, allowing them to easily penetrate hair, moisturising it inside and out.

And the ceramic feature doubles the conditioning effect on hair by eliminating the damaging hot spots and assisting in the breakdown of bacteria build-up.

SUPER STYLING GUIDE

Your best looks begin with a good haircut that's well maintained. Always treat hair right with superior quality shampoos, conditioners, and finishing products.

DRYING BASICS

1. Shampoo and condition hair with products of your choice.

Rinse thoroughly. Towel blot hair to remove excess moisture. Section hair. Using the dryer along with your styling brush, direct hot air through one section of hair at a time. Move dryer steadily across each section so that the hot air passes through hair. Direct airflow at hair, not scalp.

2. Keep dryer's air intake vents unobstructed and free from hair while drying.
3. To avoid overdrying, do not concentrate heat on any one section for any length of time. Keep dryer moving as you style.
4. For quick touch-ups between shampoos, dampen hair with a mist of water before styling with the dryer.
5. When using your dryer to create curls and waves, dry hair almost completely on a warmer temperature setting, then finish styling with Cool Setting feature to close hair shaft and lock in style.

USING THE TURBO

Dryer with Turbo Setting, please press the "Turbo" function when using 2 Heat/Speed & Integrated cool setting, it makes hair quick drying and freeze style.

USING THE CONCENTRATOR

Use the concentrator to direct airflow just where you want it. For additional control use the lower setting and point the airflow along the surface of the hair to be dried.

BODY AND VOLUME:

To help create extra body and volume in the hair, lean forward so the head is upside down when drying. Direct the airflow towards the roots for maximum lift. When hair is dry, brush back to create your required style.

STRAIGHTENING:

To create a smooth straight look, first divide the hair into sections. Attach the extra-slim concentrator use a brush to hold hair taut and roll ends slightly under as you dry.

MAKING WAVES:

To create tousled natural-looking waves position head upside down. Using the dryer without the concentrator, grasp hair at the roots and scrunch between fingertips whilst drying. When hair is dry, move your hair back into the required position for a casual and natural look.

FEATURES:

1. 1600 watts
2. Turbo Setting
3. 2 heat/speed & Integrated Cool settings
4. Ionic Port System
5. Concentrator
6. Hanging Loop

GET TO KNOW YOUR 1600W IONIC CERAMIC TURBO DRYER



USER MAINTENANCE

Your dryer is virtually maintenance-free. No lubrication is needed. For proper operating performance, the dryer must be kept clean. Blocked or clogged air intake vents will cause the dryer to overheat. When cleaning is needed, unplug the cord, and clean dust and lint from air intake openings with a small brush or the brush attachment of a vacuum cleaner. The outer surface of the dryer should be wiped clean with a damp cloth only.

If overheating occurs, an automatic safety device will shut down the dryer or the heat off to prevent damage or personal injury. If the unit or the heat cycles off, unplug the cord and allow the dryer to cool for 10 to 15 minutes before restarting. Make sure the air vents are clean.

CAUTION

Never allow the power supply cord to be pulled, twisted, or severely bent. Never wrap the cord tightly around the dryer. Damage will occur at the high flex point of entry into the dryer, causing it to rupture and short. Inspect the cord frequently for damage. Stop use immediately if damage is visible or unit stops or operates intermittently.

STORAGE

When not in use, your dryer should be disconnected and stored in a safe, dry location, out of reach of children. Do not wrap line cord around dryer.

수입 판매원
콘에어 코리아 트레이딩
서울시 성동구 성수동 308-4 서울 숲 코오롱 디지털
타워 2002호
비탈사순 고객 서비스센터
080-700-9390
www.vidalsassoon.kr

Conair Far East Ltd.,
A Subsidiary of Conair Corporate USA Conair Corporation USA,
1 Cummings Point Road, Stamford, Connecticut 06902 USA
www.toolsofsassoon.com

Vidal Sassoon and related logos are trademarks of
The Procter & Gamble Company used under license by Conair Corporation.


VS9142SK

IB-11/081

CONTINENTAL CONAIR LIMITED CHINA CREATIVE DEPARTMENT

Date	8/16/2011
Customer	VS-Korea
Model No.	VS9142SK
Description	IB
Job No.	11VS00073
Reference No.	IB-11/081
Revision No.	6
Color	1C (BLACK) + 1C (BLACK)
Open Size	552mm(W) x 214mm(H)
Folded Size	92(W) x 214(H) / mm
Material	80gsm Artpaper
Prepared by	Cherry Long
Approved by	Jimmy Ng/Liam Lee
Vendor	SILVERPLAN
Supplier	

折疊方法
Folding method:
12 pages (6 x 2)



비달사순 1600W 이온 세라믹 터보 드라이어

음이온 컨디션닝

보통의 모든 공기는 양성의 이온으로 연기, 먼지 와 공기오염에서 오는 각종 유해한 물질을 포함 하고 있습니다.

비달사순 1600w 음 이온 터보 드라이어는 음이온을 방출하여 오염된 공기를 중성화 하여 완벽하게 모발손상의 줄여 줍니다.

모발을 정화하고 깊이 활성화 시켜, 바깥쪽 표피 계층 강화하고 모발을 윤기 있고 부드럽고 건강하게 도와줍니다.

이온은 또한 작은 수분 입자로 분리되어 모발에 앞에서부터 보습을 도와주어 모발을 힘있게 가꾸어주며 쉽게 수분을 공급 할 수 있게 도와 줍니다.

세라믹 컨디션닝

본 제품은 세라믹 코팅의 특징이 있습니다. 세라믹 코팅은 열량을 골고루 배포하여 다른 드라이어 처럼 열량이 집중되어 모발손상이 될수 있는 상태를 줄일수 있습니다. 세라믹은 예열시 반사적으로 음이온을 방출하는 것으로 알려져 있습니다. 세균의 발생을 억제 하여 모발의 생명력 강화 시킵니다. 본 드라이어는 모발의 부시시함을 제거하여 부드럽고 윤기 있게 가꾸어 줍니다.

주요 안전 주의사항

제품 사용 시 특히 어린이가 있을 경우 다음의 안전 주의사항을 반드시 준수하셔야 합니다.

사용 전 반드시 사용설명서를 숙지하여 주십시오. 물에 접촉하거나 빠뜨리시면 안됩니다.

안전주의

경고: 제품 포장에 사용된 폴리에틸렌 재질의 포장재는 어린이가 사용할 경우 위험할 수 있습니다. 어린이의 손이 닿지 않는 안전한 곳에 두십시오. 유아 및 어린이 침대, 유모차, 어린이 놀이지역 안에서는 절대 사용하지 마십시오. 포장재는 장난감이 아닙니다. 얇은 막 물질이 코나 입에 붙어 유아나 어린이가 질식 될 수 있습니다.



경고: 이 제품을 욕조, 샤워장, 세면대 등 물이 닿기 쉬운 곳에서 사용하지 마십시오.



- 부득이 물이 있는 곳에서 사용할실 경우 사용 후 반드시 플러그를 뽑아 주십시오. 전원 스위치가 꺼져 있더라도 물 근처에서 사용하면 위험합니다. 보다 안전한 사용을 위하여 욕실의 잔류전류 용량은 30mA이하여야 합니다. 욕실 등에서 사용 시 위 사항을 참조하여 전문가와 상의하시기 바랍니다.
- 물 또는 액체에 절대로 빠뜨리시면 안 됩니다.
- 전원코드가 손상되었을 경우 A/S 센터에서 반드시

수리를 받으셔야 안전합니다.

- 제품 사용 시 제품의 통풍구가 막히지 않았는지 확인 후 사용하십시오. 또한 제품 후면의 흡입구가 먼지나 머리카락으로 인해 막히지 않았는지 확인하신 후 사용하십시오.
- 본 제품에는 **온도휴즈**가 장착되어 있습니다. 만약 제품의 온도가 지나치게 상승하게 되면, **온도휴즈**에 의해 자동으로 전원이 꺼지게 되거나 열이 더 이상 공급되지 않게 됩니다. 이와 같이 자동으로 꺼지는 일이 발생할 경우는 스위치를 끄시고 전원코드를 뽑으신 후 흡입구가 먼지나 모발에 의해 막히지 않았는지 확인하시고 약 10분 정도 기다리신 후 다시 사용하시기 바랍니다. 플러그와 스위치를 다시 작동시키신 후 사용해 보시고 이런 일이 다시 발생할 경우 즉시 사용을 중단하시고, A/S센터에 연락하십시오.
- 제품을 떨어뜨리시거나, 제품이 손상된 것처럼 보일 경우 사용을 중단하시고 A/S센터에 연락하시기 바랍니다.
- 전원을 연결하거나 스위치를 켜 상태에서 제품을 보관하지 마십시오.
- 제품 사용 중 문제가 있을 경우 즉시 플러그를 뽑아 주십시오.
- 제조업체가 공급하는 부속품 외의 부속품을 사용하지 마십시오.
- 제품 사용 후나 제품 세척 전에 반드시 플러그를 뽑아주십시오.
- 피부, 특히 귀, 눈, 목 등을 제품의 뜨거운 열판 사이에 닿지 않도록 각별히 주의하셔야 합니다.
- 본 제품은 영,유아, 어린이, 심신 박약자, 심신 상실자, 정신 질환자 등에 의해 사용되어서는 안 되며, 사용 시에는 반드시 보호자의 보호가 필요합니다. 특히 어린이가 장난감처럼 사용하지 않도록 각별히 보호해 주십시오.
- 제품 보관시 반드시 제품을 식혀 주십시오.
- 전원코드의 손상을 막기 위해 꼬거나 구부려서 보관하지 마아 주십시오.

사용방법

이온 세라믹 컨디션닝의 특징

현대 환경에는 에어컨, 인조섬유, 오염된 공기 등의 유해한 성분의 영향으로 발생하는 정전기로 인하여 모발에 영향을 줄 수 있는 요인이 많이 있습니다. 심지어 빗질을 하거나 타월로 모발을 건조하여도 모발의 표피와 표면을 거칠게 하여 모발에 심한 손상을 줄 수 있습니다. 또 강한 정전기는 모발을 날리게 하여 스타일 연출을 어렵게 합니다. 음이온은 모발의 정전기를 중화시켜 모발의 표면을 매끄럽고 부드럽고 윤기 있는 모발로 연출하여 쉽게 원하는 헤어스타일 연출을 도와 줍니다. 음이온은 수분을 작은 입자로 분해 하여 모발 표면은 물론 모발 깊숙이까지 고루 스며들 수 있도록 도와줍니다. 또한, 세라믹 특징은 열이 집중되어 모발이 손상될수 있는 성분을 제거하고 세균 번식을 억제하여 2배의 컨디션닝

효과를 보실 수 있습니다.

스타일링 가이드

최고의 스타일의 시작은 잘 정리된 헤어 입니다. 모발을 항상 좋은 품질의 샴푸와 컨디션닝을 하여 관리하도록 합니다.

기본 드라이

- 샴푸와 컨디션닝을 본인의 모발에 맞는 제품으로 선택 하십시오. 샴푸 후 모발을 수건으로 닦아서 젖을 물기를 제거 합니다. 어느 정도 마른 모발을 드라이가 편리하게 구분 한후 원하는 스타일에 맞게 나누어진 부분을 드라이 합니다. 이때 뜨거운 열이 두피에 닿지 않도록 주의 하십시오.
- 모발이 움직이지 않게 공기가 모발 사이로 골고루 스며들 수 있도록 드라이 합니다.
- 모발이 너무 건조해지지 않도록 한군데만 집중하여 드라이 하지 마십시오. 스타일연출을 위해 계속 드라이를 움직이십시오.
- 스타일링 하기 전에 샴푸 후 빠르게 손질하고 모발이 축 늘어졌을 때에는 모발에 수분을 뿌린 후 스타일링 합니다.
- 드라이를 사용 하여 웨이브나 컬 연출을 할 때에는 드라이 온도를 높은 곳에 고정 후 드라이 합니다. 스타일 완성된 이후 에는 냉풍에 고정하여 연출된 스타일이 고정되도록 합니다.

터보 기능 작동 방법

드라이의 터보 기능을 사용 시에는 터보 (Turbo) 버튼을 누른 후 2단 온도/풍속 & 냉풍 기능 사용시 모발을 좀더 빠르게 건조하고 스타일링 하실 수 있습니다.

중양 집중 노즐 사용 방법

중양집중 노즐은 공기를 이용하여 원하는 부위에 직접적으로 스타일 연출을 도와 줍니다. 섬세한 사용을 원하는 경우 낮은 열풍으로 설정 후 모발 표면에 따라 모발을 건조합니다

블룸 연출

풍성한 블룸 연출을 원하실 경우에는 고개를 숙인 후 드라이를 합니다. 공기를 모근으로 향하게 하여 드라이를 하여 최대한 모발을 세우 도록 합니다. 모발이 건조된 이후에는 고개를 들고 빗질하여 원하는 스타일을 완성합니다.

스트레이트닝

부드러운 모발의 스트레이트 스타일 연출 시에는 먼저 머리를 섹션 별로 구분합니다. 중양집중노즐을 부착 후 브러시로 모발을 팽팽하게 잡아 당겨 드라이로 쓸어 내리면서 스타일링 합니다.

웨이브 연출

자연스런 웨이브 연출 시에는 고개를 숙입니다. 중앙 집중 노즐은 제외한 드라이어로 모발을 적당량을 원하는 웨이브 스타일로 모근까지 켜 후 손가락으로 말아 가면서 드라이 합니다. 어느 정도 드라이가 되면 고개를 들어서 스타일링 하여 마무리 합니다.

제품 특징

- 1600W
- 터보 기능
- 2단 온도/풍속 & 냉풍 기능
- 음이온 시스템
- 중양 집중 노즐
- 걸이용 고리



사용시 주의 사항

본 제품은 별도의 유지 보수를 필요로 하지 않습니다. 유타류 첨부를 필요로 하지 않습니다. 적절한 사용을 위해서는 제품을 반드시 깨끗한 상태로 유지 하여야 합니다. 차단되거나 막힌 공기 투입구는 드라이 과열의 원인이 됩니다. 세척이 필요할 경우, 전원을 끄고 열기가 식은 상태에서 에어 투입구를 개봉 후 작은 브러쉬를 이용하여 먼지와 이상물질을 제거 하도록 합니다. 드라이어의 다른 표면은 젖은 천으로 닦아서 청소 합니다.

만일 과열될 경우 전원이 자동으로 차단 되며 작동이 중지되어 제품 손상을 예방하고 다칠 수 있는 부상을 방지합니다. 제품이 자동 전원 차단 될 경우 전원을 차단 후 플러그를

분리 후 제품을 10-15분 정도 차갑게 한 후 다시 사용 하도록 합니다.

사용 전 반드시 에어 통풍구의 청소상태를 확인 하십시오.

위험

절대로 전선을 잡아당기거나 꼬는 등 심하게 구부리지 마시고 전선으로 기기를 너무 단단히 감지 마세요. 이는 전선의 손상 및 파열, 합선문제를 발생시킬 수 있습니다. 전선을 수시로 확인하시고 손상됐을 시엔 제품사용을 즉시 중단하시기 바랍니다

제품 보관

제품을 사용하지 않을 때는 반드시 전원을 안전 하게 분리하고 제품을 차갑게 한 후 어린이의 손이 닿지 않는 안전하고 건조한 곳에 보관하십시오. 전원에서 분리할 때는 갑자기 잡아당기거나 너무 팽팽하게 전선을 잡아당기지 마시고 전선으로도 제품을 감지 마십시오.

제품 품질 보증서	
성명	
전화번호	/휴대폰번호
e-mail	
주소	
구입일자(년/월/일)	
모델번호(사용설명서 앞면 표기)	
대리점명(구입처)	
■ 주의사항	
	· 서비스를 받고자 하실때는 이 보증서의 구입 영수증을 제시하여 주십시오.
	· 제품 구입일자가 고쳐지거나, 지워졌을 경우에 본 보증서는 무효입니다.
	· 이 보증서를 분실하실 경우, 재발행되지 않습니다.
본 보증서는 보관하십시오	
■ 품질 보증의 조건	
	· 본 제품의 품질보증 기간은 구입 일자로부터 2년간 입니다.
	· 일상적인 사용에 의한 제품의 마모나, 미열 또는 천재지변에 의한 제품의 손상 및 사용 설명서 상의 주의사항을 따르지 않고 임의로 사용하거나, 취급부주의로 인한 고장 등에 대해서는 본 보증서에 의한 무상 서비스를 받을 수 없습니다.
	· 품질 보증서 상의 보증기간 내에는 제조상 또는 제질상의 결함으로 발생한 불량 등에 대하여 무상 서비스를 받을 수 있으며 폐사의 판단에 따라 부품의 교환 또는 제품의 교환도 가능합니다.
	· 본 보증서의 효력은, 품질 보증서와 보증 등록서상의 대리점의 판매 확인과 제품구입 후 4주 이내 보증등록서가 고객 서비스 센터에 우송 되었을 때로부터 발생 합니다.
	· 본 제품 품질보증은 수입판매원의 관할 이외 지역과 적법하게 위임 받지 않은 판매처의 보증일 경우 효력을 상실합니다.
서비스를 받으시고자 할 경우 보증서의 내용을 기록하여 제품과 함께 보내주십시오.	
수입 판매원 르에어 코리아 트레이딩 서울시 성동구 성수동 308-4 서울 순 코오롱 디지털 타워 2002호 비달사순 고객 서비스센터 080-700-9390 www.vidalssassoon.kr	